

TECHNICAL INFORMATION

FOR PROFESSIONLA USE ONLY



BRAYT HEADLIGHT RESTORATION KIT

TARNISHED HEADLIGHT

HAND APPLICATION

1. BRAYT T11 POLISHING COMPOUND + BRAYT MICROFIBRE CLOTH* – polish until surface becomes smooth.
2. BRAYT T4 PROTECT LIQUID + BRAYT MICROFIBRE CLOTH* - rub into headlight and leave until min. 1 hour. After this time carry out final polishing.

MACHINE APPLICATION

1. BRAYT T11 POLISHING COMPOUND + BRAYT „PROFI” POLISHING SPONGE* or BRAYT POLISHING LAMBSWOOL „MM” 80 mm* – polish until surface becomes smooth.
2. BRAYT T4 PROTECT LIQUID + BRAYT MICROFIBRE CLOTH* – rub into headlight and leave until min. 1 hour. After this time carry out final polishing.

HEADLIGHT WITH DAMAGED PROTECTIVE LAYER

HAND APPLICATION

1. Grind using P1500 to P2500 sandpaper to remove all defects.
2. BRAYT T11 POLISHING COMPOUND + BRAYT MICROFIBRE CLOTH* – polish to remove all defect, until surface will be fully transparent.
3. BRAYT T4 PROTECT LIQUID + BRAYT MICROFIBRE CLOTH* – rub into headlight and leave until min. 1 hour. After this time carry out final polishing.

MACHINE APPLICATION

1. Grind using P600 to P1500 sandpaper to remove all defects.
2. BRAYT T11 POLISHING COMPOUND + BRAYT POLISHING LAMBSWOOL „MM” 80 mm* – polish to remove all defects, until surface will be fully transparent.
3. BRAYT T4 PROTECT LIQUID + BRAYT MICROFIBRE CLOTH* – rub into headlight and leave until min. 1 hour. After this time carry out final polishing.

*Recommended products. Not included in kit.

All information are based upon the precise laboratory studies and many years of experience. The good market position does not release us from the constant supervision of our products quality. However we are not responsible for the final effects of the improper storage or application of our products, as well as for work inconsistent with the good craft practice.

TROTON Sp. z o.o.
Ząbrowo, Poland.